

## Post Start up Inspection (Gensets)

### To start the genset:

- Hold glow plug switch on for 30 seconds
- Push switch passed the on position and hold until unit starts
- Once started release the On switch and the unit should stay running
- **\*\* Note some units require the on switch and the glow plug switch to be held up at the same time to start.\*\***

### Once the unit is running check:

- Oil pressure gauge
- Ammeter is charging
- Water temperature is normal
- Any fuel/oil/coolant leaks
- Listen for anything that could be a problem
- Turn on main breaker to power cable if equipped

### Go to the front of the container and ensure:

- The power switch or button is on (if equipped)
- The screen on the container is on

## Points to Remember

- **All Defects must be reported on a defect report and to dispatch immediately.**

